

OIL FINISHED END GRAIN FLOOR AFTERCARE INSTRUCTIONS

DAILY/WEEKLY

Sweep &/or Gently Vacuum

Use WOCA Natural Soap Spray

- Do not use vacuum with beater bar running, use suction only. Backpack vacs are excellent.
- Spray WOCA Natural Soap Spray regularly in High Traffic areas to help remove dust & dirt.
- Wipe Up all spills and water immediately.

SPOT TREATMENTS

USE WOCA Natural Soap Spray

- Spray affected area and wipe dry immediately.

MONTHLY/QUARTERLY

Use WOCA REFRESH SPRAY

- Spray WOCA Refresh Spray in high traffic areas, wipe dry immediately.

ANNUAL/BI-ANNUAL

Use WOCA COMMERCIAL
CLEANING OIL

Requires use of slow speed buffer,
buff pads and polishing **cloths**.

Call Kaswell Floors
to order all
WOCA PRODUCTS.
855-495-2224
Kaswell-Kare.com



Kaswell Flooring Systems
NEXT GENERATION FLOORING, LLC
The wood block flooring specialists

Kaswell-Kare.com

This program is designed to use as little water as possible to prevent expansion of the flooring. **PLEASE DO NOT WET MOP FLOORS AS HEAVY WATER EXPOSURE CAN DAMAGE THE FLOORING.**

The best way to care for your Oil finished END GRAIN floor is to prevent buildup of dust and dirt. Clean spills as they occur with a CLEAN dry cloth or use WOCA NATURAL SOAP SPRAY to spot treat spills. **PLEASE USE ONLY WOCA CARE & MAINTENANCE PRODUCTS.** Use of other manufacturer products can result in a cloudy, contaminated finish.

WOCA NATURAL SOAP & WOCA REFRESH OIL SPRAY are available in White or Natural. Please order according to your finish color. Please **ONLY** use in Spray Bottle application.

The scheduling of your WOCA COMMERCIAL CLEAN BUFF clean is determined on traffic and food use. High traffic commercial spaces may benefit from more frequent buff cleaning. Standard Residential Care or very light Commercial Office Space use typically schedule a buff cleaning at 18-24 months from initial finish.

The beauty of an Oil Finish floor is that it can be corrected without re-sanding. If your floor has NOT been regularly cared for with the appropriate WOCA Soap Spray or WOCA Refresh Spray it will benefit from a buff cleaning with WOCA Commercial Cleaning Oil.

WOCA COMMERCIAL CLEANING OIL cleans the floor without using water. It keeps the floor properly saturated with oil helping to keep dirt on the surface instead of into the wood grain. Sections can be done at regular intervals. Work can be done in the evening and walked on in the morning.

WOCA Commercial Cleaning Oil Method:

TOOLS: Slow Speed Buffer, WOCA Commercial Cleaning Oil, Red or White buff pads, WOCA polishing cloths and clean terry cloth towels.

WORKING METHOD: Spray WOCA Cleaning oil on small surface area, wet buff the cleaning oil into the floor. Do not let a sprayed area rest for more than one hour, work in small sections. A 2nd buffer, with a WOCA Polishing cloth wrapped around a clean white pad could be used to remove the excess oil from the floor. A two man crew should complete approximately 700 sf per man hour.

DRYING TIME: A final dry polish is recommended to remove any excess or remaining WOCA Commercial Cleaning Oil. Any latent greasiness on the floor will attract dust, dirt and show footprints. If you think you've buffed enough, buff off one more time with a clean terry towel wrapped under buff pad, this will also insure appropriate dry time. With appropriate ventilation, most floors can be walked on after 4-6 hours, preferred dry time is 8-12 hours.

WARNING: Rags, pads or waste soaked with WOCA OIL may self-ignite if improperly discarded. Immediately after use, place all rags and waste in a sealed, water filled bucket for proper disposal.